

INSTRUCTIONS

LED PROJECTOR GALAXYLIGHTS

PACKAGE CONTENTS

- GalaxyLights projector
- Remote
- USB cable
- Instructions

TECHNICAL SPECIFICATIONS

- Power supply: USB DC 5 V/2 A
- Remote power supply: 2 AAA batteries (not included)
- Max LED power: 2 × 4 W
- Size: 16 × 11 cm
- Weight: 369 g
- Material: ABS



COMPONENTS




1. USB flash drive input
2. Brightness adjustment
3. Reduce volume/previous song
4. Increase volume/next song
5. Mute/Bluetooth ON or OFF
6. USB flash drive/Bluetooth mode
7. USB cable input
8. ON/OFF switch

HOW TO USE

- Plug one end of the included USB cable into a charger, a computer, or a power bank and the other end into the USB cable input (7) on the side of the device.
- Turn on the device by using the ON/OFF switch (8).
- Use the brightness adjustment button (2) to control the LED or laser brightness. With a short press of the button, you control the LED brightness, and with a long press, the laser brightness.
- This device has a built-in Bluetooth speaker. You can listen to music from your USB flash drive that you insert into the USB flash drive input (1) or use your smartphone to play the music via Bluetooth.
- To connect your phone with the device, long press the Bluetooth ON/OFF button (5) and select BTK10 on your list of available devices.
- Use the volume buttons (3 and 4) to control the volume or skip songs.
- Use the USB/Bluetooth button (6) to switch between the USB flash drive or Bluetooth playing modes.
- You can also use the included remote to control the device.

REMOTE CONTROL

Open the plastic cover on the back of the remote and insert 2 AAA batteries (not included).



1. LED ON/OFF button
2. Laser ON/OFF button
3. Red LED light ON
4. Green LED light ON
5. Increase volume
6. Skip to the previous song
7. Skip to the next song
8. Sound activated lighting mode
9. Decrease volume
10. Blue LED light ON
11. White LED light ON
12. Increase speed of the LED pattern
13. Decrease speed of the LED pattern

14. Long press to cancel auto-off function
15. Automatic fading mode 1
16. Control LED brightness
17. Automatic fading mode 2
18. Laser fading mode
19. Long-press to set the auto-off function to 1 hour
20. Long-press to set the auto-off function to 2 hours
21. Music ON/OFF button

Note: The device turns off automatically after 4 hours of use.


WARNINGS

- Do not look directly into the lights. This might cause eye damage or even blindness.
- Always turn off and disconnect the device when not in use.
- Store in a dry and dark place. The device can be damaged by water or moisture.
- Keep away from open flames and heat.
- This device is not a toy. Keep away from children.
- Only use the product for its intended purpose.
- Do not disassemble or modify in any way.
- Only use the included USB cable.

WARRANTY

The warranty is valid for 24 months. You can claim it from DFCU d.o.o., Liparjeva 6a, 1234 Mengeš, Slovenia, for a replacement product or a refund. Send us your order number and purchase date in the email, which is available by clicking on our logo in the bottom right corner. The product has a lifetime of 24 months from the date of collection.



	WEEE disposal and recycling symbol. The WEEE symbol is attached to the product in compliance with the EU directive 2012/19/EU on Waste Electrical and Electronic Equipment (WEEE). It is intended to deter the improper disposal of this product and to promote reuse and recycling.
---	--