# INSTRUCTIONS

# PROFESSIONAL GYPSUM BOARD CUTTER EXACTX

#### **PACKAGE CONTENTS**


- Handle (2 parts)
- 2 × handle-fixing screws
- 2 × guide leg
- Guide leg mount
- Blade holder (2 parts)
- 2 × blade
- 4 × replacement bearings
- 6 × screw
- 6 × washer
- 6 × nut
- Instruction manual

### **TECHNICAL SPECIFICATIONS**

- Cutting range: 20–600 mm
- Size: 730 × 320 × 120 mm
- Weight: 1.6 kg
- Material: ABS, stainless steel
- Max board thickness: 12 mm



# **COMPONENTS**



- 1. Guide legs
- 2. Handle parts
- 3. Guide leg mount
- 4. Handle-fixing screws
- 5. Blades
- 6. Screws, washers, and nuts
- 7. Blade holder
- 8. Replacement bearings

### **HOW TO ASSEMBLE**

Note: Use the instruction manual that's included in the package for reference when assembling the product.

• Take the handle and insert the guide legs through the opening in the middle of the handle.

- Then take the guide leg mount and insert the guide legs into it.
- Fix the handle in place with one of the handle-fixing screws. Screw the auxiliary handle on the other side.
- Take the two blade holder parts and fix them to the bottom of the device with the included screws. Use the smaller screws on the middle openings. Do not forget to put washers on the screws. Do not fully tighten the nuts just yet.
- Take the blades and shorten them by snapping them to the desired length. Be careful when handling the blades, they are extremely sharp. Insert them into the blade holders and tighten the screws that hold them in place.
- The product is now ready for use. Slide the handle up and down to determine the desired cut length, then fix it in place with the handle-fixing screw before cutting.

### WARNINGS

- Only use the product for its intended purpose.
- Wear safety equipment when using the product.
- Carefully handle the blades, they are extremely sharp and can cause serious injuries.
- Do not disassemble or modify in any way.
- Keep away from heat and moisture.
- Do not attempt to cut gypsum boards thicker than 12 mm.



#### WARRANTY

The warranty is valid for 24 months. You can claim it from DFVU d.o.o., Liparjeva 6a, 1234 Mengeš, Slovenia, for a replacement product or a refund. Send us your order number and purchase date in the email, which is available by clicking on our logo in the bottom right corner. The product has a lifetime of 24 months from the date of collection.



