

# INSTRUCTIONS

## KALIMBA

### PACKAGE CONTENTS

- Kalimba
- English instructions
- Stickers
- Cleaning cloth
- Storage bag
- Tuning hammer

### TECHNICAL SPECIFICATIONS

- Size: 18 × 3 × 13 cm
- Material: mahogany, stainless steel
- Weight: 600 g



### PARTS




1. Backstop
2. Z-Bracket
3. Bridge
4. Tines
5. Sound hole

### HOW TO USE

#### Tuning

- The 17-tine kalimba comes tuned in the C-major scale out of the box, but you might have to do some extra tuning to make it sound perfect.
- You will need a tuner (not included) or a tuner app for your phone (there are free tuner apps for Android and iOS available, choose one and try it).
- Consult the following chart, then tune each tine to the corresponding note.



- Use the included tuning hammer to dial in each tine.
- If the tuning is too low, slightly push the tine upwards. And if the tuning is too high, slightly push it downwards.

#### How to play


- There are two ways to play the kalimba.
- Set the kalimba on a flat surface and use your index fingers to play it, or hold it in your hands and use your thumbs.
- See the following picture for reference.



- Use with clean hands to prevent dirt buildup, and wipe the tines after every use to preserve sound quality.

### WARRANTY

The warranty is valid for 24 months. You can claim it from DFVU d.o.o., Liparjeva 6a, 1234 Mengeš, Slovenia, for a replacement product or a refund. Send us your order number and purchase date in the email, which is available by clicking on our logo in the bottom right corner. The product has a lifetime of 24 months from the date of collection.



### *Storage and care*

- When not in use, store the kalimba in the included bag.
- Do not expose to moisture or liquids of any kind. This can damage the box and make your kalimba lose its unique sound.