

INSTRUCTIONS

RECON WILDLIFE CAMERA

PACKAGE CONTENTS


- Trail cam
- Strap
- USB charging cable
- USB to microSD adapter
- Instruction manual

TECHNICAL SPECIFICATIONS

- Image sensor: 3 MP color CMOS
- Photo resolution: 12 MP
- Video resolution: 1080p full HD @ 25 fps
- Lens angle: 120°
- Sensor range: 15 m
- MAX microSD size: 32 GB (not included)
- Power supply: 4 × AA battery (not included)
- Water resistance: IP56
- Standby time: 12 months
- Size: 55 × 90 × 135 mm
- Weight: 160 g



COMPONENTS



1. Battery compartment 1
2. Micro-USB power supply
3. MicroSD slot
4. ON/OFF switch
5. Battery compartment 2
6. Locking screw

HOW TO INSTALL THE BATTERIES

- Open the hub at the bottom of the camera by unscrewing the locking mechanism.
- Press onto the battery compartment cover to open it.
- Insert two AA batteries (not included) into each slot.

- Make sure to check the polarity. It is written on the metal part of the battery compartment cover.
- Close the cover.

HOW TO SET UP THE CAMERA

- Insert a microSD (not included) into the slot.
- Insert the batteries or connect the micro-USB cable to power supply at the bottom of the camera – use the rubber cover.
- Use the included strap to fasten the camera to a desired location.
- Turn the camera ON using the ON/OFF switch.
- The camera will take 3 pictures and record 10 seconds of video each time the sensors detect movement in the detection range.
- It enters standby mode until the next time the sensor detects movement. It can remain in standby mode up to 12 months.
- To set the time and date of the recordings, open a text file on your computer and write the current date and time in it in the following format: 2020-11-11 12:59:59 332Y. Name the file time.txt and save it to the microSD card that you will use with the camera.

WARNINGS

- Only use the product for its intended purpose.
- Do not disassemble or modify in any way.
- The product can only operate in temperatures from -10 to 70 °C.

- Do not submerge in water.

WARRANTY

The warranty is valid for 24 months. You can claim it from DFCU d.o.o., Liparjeva 6a, 1234 Mengeš, Slovenia, for a replacement product or a refund. Send us your order number and purchase date in the email, which is available by clicking on our logo in the bottom right corner. The product has a lifetime of 24 months from the date of collection.



WEEE disposal and recycling symbol.
The WEEE symbol is attached to the product in compliance with the EU directive *2012/19/EU* on Waste Electrical and Electronic Equipment (WEEE). It is intended to deter the improper disposal of this product and to promote reuse and recycling.