

## INSTRUCTIONS

### EXTENDABLE DUSTER MEGACLEAN

#### PACKAGE CONTENTS

- MegaClean duster

#### TECHNICAL SPECIFICATIONS

- S length: 40–89 cm
- L length: 80–250 cm
- Material: PP, stainless steel, polyester fibers



#### USAGE

- The MegaClean extendable duster is used to clean and get rid of dust, pollen, and pet hair in hard-to-reach places.
- If you are using the large MegaClean duster, you must first screw the duster head onto the telescopic handle. If you are using the small duster, this step isn't required.
- Start by adjusting the length of the duster. Extend the telescopic handle by holding the metal section of the handle with one hand, then pull the rubberized end of the handle outwards.
- Along with adjusting the length, you can also vary the angle of the duster head. Use both your hands to transform the head into any shape you want gently.
- Your duster is now ready to clean. To begin dusting, simply brush the fibers over dirty surfaces, spin them around small objects, or use back and forth wiping motion.
- When the duster head becomes soiled with dust, rinse the duster in the sink with warm water, and leave it to dry to make the duster head fluffy again.

#### WARRANTY

The warranty is valid for 24 months. You can claim it from DFVU d.o.o., Liparjeva 6a, 1234 Mengeš, Slovenia, for a replacement product or a refund. Send us your order number and purchase date in the email, which is available by clicking on our logo in the bottom right corner. The product has a lifetime of 24 months from the date of collection.

