INSTRUCTIONS

RAPIDRIVET RIVET SET

PACKAGE CONTENTS

- Riveter
- 7 × nosepiece
- 90 × M3 rivet
- 65 × M4 rivet
- 50 × M5 rivet
- 40 × M6 rivet
- 30 × M8 rivet
- 20 × M10 rivet
- 5 × M12 rivet
- Instructions
- Specialized wrench

TECHNICAL SPECIFICATIONS

- Size: 44 cm
- Weight: 1.35 kg
- Material: high-carbon steel



EXCHANGING A NOSEPIECE

- Begin by choosing the right nosepiece and rivet for the hole.
- You will need to exchange the nosepiece.
- To do so, unscrew the nut holding the nosepiece in place with the included wrench.
- Then unscrew the ring at the base of the riveter to remove the holding mechanism.
- Slide the sleeve of the nosepiece down to expose the nosepiece and unscrew it from the socket.
- Repeat the process in reverse to install the new nosepiece.

Note: The M8 nosepiece is already installed in the riveter by default.

HOW TO USE

- Open the arms of the riveter.
- Screw the correct rivet onto the nosepiece.
- Insert the rivet into the hole and close the arms of the riveter so that the rivet is held in place.
- Unscrew the riveter from the rivet either by rotating it or using the knob on the back of the riveter.

WARNINGS

• Only use the included rivets.

- Make sure you're using the correct nosepiece for each rivet. Using the wrong one might result in the riveter getting stuck.
- Do not disassemble or modify in any way.
- Only use the tool for its intended purpose.

WARRANTY

The warranty is valid for 24 months. You can claim it from DFVU d.o.o., Liparjeva 6a, 1234 Mengeš, Slovenia, for a replacement product or a refund. Send us your order number and purchase date in the email, which is available by clicking on our logo in the bottom right corner. The product has a lifetime of 24 months from the date of collection.



