

## INSTRUCTIONS

### FLORAL DECORATIONS SET FOR CAKES

#### PACKAGE CONTENTS

- Bag
- 7 × nozzle (12 in the 27-piece set)
- 2 × attachment
- Cleaning brush
- 10 × additional bag (only in the 27-piece set)

#### TECHNICAL SPECIFICATIONS

- Material: silicone, metal, plastic



#### COMPONENTS



1. Floral nozzles
2. Decorative nozzles
3. Cleaning brush
4. Three-way attachment
5. Decorative nozzle attachment
6. Bag

#### HOW TO USE

- Take the bag and cut off 2.5 cm of the bag at the nozzle (front of the bag, where the icing or cream would come out).
- Unscrew the ring of the attachment and slide it into the bag.
- Take the nozzle and place it over the attachment. Screw the ring back in place so that it holds the nozzle.

- You can also use the nozzles without the attachment. Just put it in the bag so that it's looking out of the front end.
- You can use the three-way attachment to make three-colored decorations.
- Unscrew the ring on the attachment then take the three pieces apart and put them in three bags. (you will need to buy additional bags, or use the ones that are included in the 27-piece set)
- Bring the pieces together so that they match. There are numbers written on the pieces – they should match.
- Put the floral nozzle over the attachment and fasten everything with the ring. The three-way attachment is now ready to use.
- Fill the bag with icing or cream to use.

#### MAINTENANCE

- When you are done with decorating, take all the pieces of the nozzle and attachments apart and clean them. You can clean them in the dishwasher.
- The bag can also be cleaned in the dishwasher.
- Clean after each use.

#### WARRANTY

The warranty is valid for 24 months. You can claim it from DFCU d.o.o., Liparjeva 6a, 1234 Mengeš, Slovenia, for a replacement product or a refund. Send us your order number and purchase date in the email, which is available by clicking on our logo in the bottom right corner. The product has a lifetime of 24 months from the date of collection.

