

INSTRUCTIONS

WET SAND BLASTING SET POWERBLAST

PACKAGE CONTENTS

- Hose
- Sand inlet
- Pressure washer attachment

TECHNICAL SPECIFICATIONS

- Hose length: 275 cm
- Material: rubber, steel, ABS
- Attachment type: 1/4"



COMPONENTS



1. Pressure washer attachment
2. Sand inlet

HOW TO USE

Note: Always use protective equipment such as protective gloves, respirator or dust mask, and goggles during sand blasting.

- This product is only an attachment and requires a high-pressure washer to operate.
- You will also need a bucket filled with dry silica sand (0.2–0.6 mm granules).
- First, attach the hose to the nozzle.
- Attach the device to your pressure washer and make sure it's securely tightened.
- Insert the sand inlet into a bag or bucket filled with sand. Make sure it's covered completely.
- Use the pressure washer to remove rust, paint, and other materials from surfaces.

See the pressure washer's instructions for additional information regarding its use.

- If your pressure washer's pressure is high enough, the Powerblast sand blasting set will create negative pressure and suck the sand into the water jet.

WARNINGS

- Always use protective equipment such as protective gloves, respirator or dust mask, and goggles during operation.
- Never aim the nozzle at humans or animals. This device can cause serious harm or injury.
- Do not disassemble or modify in any way.
- Use this product only for its intended purpose.

WARRANTY

The warranty is valid for 24 months. You can claim it from DFVU d.o.o., Liparjeva 6a, 1234 Mengeš, Slovenia, for a replacement product or a refund. Send us your order number and purchase date in the email, which is available by clicking on our logo in the bottom right corner. The product has a lifetime of 24 months from the date of collection.

